


UTS-485TB



Termination resistors :

UTS-485TB			Termination Resistor 120 Ω
Pin	J1	J2	
Jumper	ON	ON	Enable (default)
Jumper	OFF	OFF	Disable

Loop Back

UTS-485TB			Loop Back
Pin	J6	J7	
Jumper	ON	OFF	Disable(Default)
Jumper	OFF	ON	Enable